

EDM Modal Test Case | Sound of Mode Shapes

by Aakash Umesh Mange - Senior Application Engineer www.crystalinstruments.com | info@go-ci.com | © April 2024

A violin was suspended on a frame to a imitate free-free boundary condition. Sentek Dynamics' BT-100M shaker was used to excite a violin at the base of its front panel. Polytec's PSV500 laser scanner was used to measure and acquire the data from the back panel of the violin. Crystal Instrument's EDM Modal software processed and analyzed the dataset to provide the modal parameters of the violin. (Figure 1.)

The coordinates of 186 measurement points spread across the back of the violin were used to create the geometric model of the violin under test. (Figure 2.)



Figure 1. Violin Modal Test Experimental Setup



Figure 2. Violin Geometry Model

The measured FRFs were imported to analyze the dominant peaks in the desired frequency range. (Figure 3.)

Modes were appropriately identified in various stages using the Complex Mode Indicator Function (CMIF) and the Poly-X curve-fitter. (Figure 4)

Geometry Koltor 🕕	Input Channel 5	letup 🕀 Output	i Channel Setup	E Store MMO H	Measurement E Model Dat	Telestion - Band Selector - Stability Dagues - Animaton - Stynmess - COS - Consiston	
nal candidates for model calculation						(Scan, J., Transfer Function H1(14)(+152+12)	
and Billion 1						Forgette service - Scan 3 Transfer Fundion Hits (1911)	
science: P.X. P.Y.	42.41	12 22	95 9 Deg	tay select signal entry	Valuate 1	i i i i i i i i i i i i i i i i i i i	
nal hane	Celculate mod	IN DOPS	Onit	Signal source	Compatibility #	" month him	
Stansfer Function H1_		+12-12	im/g/M	Scan 3	Linear Lines 5625 8F.8		
Transfer Function H1	14	+22-12	1m/d/74	Scan 1	Linear Lines 5625 AF3	1.001	
Transfer Function H1_	14	+32-12	(m/d/94	Scan 2	Linear Lines 5625 AF 2	8.0001	
Transfer Function H1_	La la	+42:+12	(m/i0/24	Scan 3	Linear Lines 5625 AF 8		
Transfer Function H1	12	+52 +12	in/d/N	Scan 1	Linear Lines \$625 AF3	Provide the state of the state	
Transfer Function H1_	24	+62+12	(m/d/74	Scan 3	Linear Lines 5625 AF3	Plan Bayres Scan_3_Transfer Function Hits14gi 15	
Transfer Function H1		+72+12	10/10/24	Scan 3	Lines Lines 5625 AF 8	The second secon	
Transfer Function H1_	2	+82+12	10/0778	Scan 2	Linesr Lines 5525 AF2	HI Martin M	
Transfer Function H1_	2	+92+12	(m)(c/04	Scon 1	Linear Lines 5625 AF3		
Transfer Function H1	3	+102-12	(m/d/08	Scan 3	Linear Lines 5625 AF3		
Transfer Function HT.		+112-12	10/0774	Scan 2	Linear Lines \$625 AF 3	* min mal	
Senater Function H1.	24	+122-12	Im/o/N	Scan 3	Linear Lines 5625 A73		
Transfer Function H1	2	+132 +12	im/d/7M	Scan 1	Linear Lines \$625 AF3	per per	
Transfer Function H1_		-142-12	10/0778	Stan 1	Linear Lines 5625 AF3	No. 10 200 200 400 100 400 700 800 400	
Sandar Function 111		+157 +17	Invicting.	Stan 1	Linesr Lines 5635 AF3		
Transfer Function 111-	34	+167 +12	level (N	Scan 1	Linear Lines 5625 AT 3	Geometry Display	
Transfer Function H1		+172 +12	im/d/74	Scan 1	Lines Lines 5625 AF3	0 0 0 0 0 0 · · · · · · ·	
Sanda Function H1	100	+187 +17	14-10-178	Scan 1	Linear Lines 5625 AF3	Zermin Zoon Con Anto State Roman Zoonlate State Line Surface Model Clinics Gale Insta-	
Transfer Function if 1		-107-17	Including.	Scin 3	Linear Lines \$625 AF 2	The second	
Namelia Function (r)	iar .	-107 -17	in July 18	Scan 3	Lines Lines 5625 AFE	District Section	
Sander Function H1		-217-17	(min) (TA	Scan 1	Lines Lines \$635 AF3	Perspective	
Transfer Runction H1		+727-12	indd/M	Scan 1	Linear Lines 5675 AFT		
Namelar Function M1.		+117 + 17	induited.	Scan I	Lines Lines 5535 AET	AT A A A A A A A A A A A A A A A A A A	
Samle Function H1.		+242+12	incluing.	Scan 2	Linear Lines 5625 AF3	ATTRACT	
Transfer Exection #1	100	-267 - 17	Including.	Scan 3	Linest Lines 5625 AF1	AT#1568354	
Standar Exection M1.		+ 767 + 17	daughter and	Scin I.	Lines Lines 5675 AER	× KARANAN	
Sumly Function M1.		.377.417	1-10720	Scan 3	Lower Lower SA35 AF 2	DREEKS ARCEN	
Standar Exection M1	14	- 107 - 17	in the set	from 3	Linest Lines \$675 ALT	THE HEAR STATE AND A STATE	
Supply Function M1		-107-12	(m)()/74	Scan 2	Lines Lines 5635 A52	NAT SKEWER AND	
Second of Franking M1	-	100.00	in south	form 2	Longer 1 (1997 56 75 AS 3		
Support Publication 11		- 347 - 17	includes.	Scan 1	Linear Linear 5625 AE3		
Sanda Fuerback		-127.47	10010178	Second P	Linear Lines 5615 AS 3		
Sander Function H1_	2	*264 × 16	000000	SCHU'S	Linear, Lines 5925, 07.3	DIDOKOV VY	
Render Function 1/7		-147-17	1000000	free 1	Linear (Jaco \$455 AT 1		
Reading Franciscon Hill.	-	147.47	In NOR	Acres 1	Contex, 10413923, 213		

Figure 3. Modal Data Selection tab showing the Measured FRFs



Figure 4. Stability diagram for selected modes

Some of the extracted modes are animated below.



Figure 5. Mode Shapes of the violin

Crystal Instruments Corporation 2090 Duane Avenue Santa Clara, CA 95054 Crystal Instruments Testing Lab 15661 Producer Lane, STE H Huntington Beach, CA 92649 Crystal Instruments Testing Lab 1548A Roger Dale Carter Blvd Kannapolis, NC 28081 Phone: +1 (408) 986-8880 Fax: +1 (408) 834-7818 www.crystalinstruments.com

© 2024 Crystal Instruments Corporation. All Rights Reserved. 05/2024

Notice: This document is for informational purposes only and does not set forth any warranty, expressed or implied, concerning any equipment, equipment feature, or service offered or to be offered by Crystal Instruments. Crystal Instruments reserves the right to make changes to this document at any time, without notice, and assumes no responsibility for its use. This informational document describes features that may not be currently available. Contact a Crystal Instruments sales representative for information on features and product availability.