


Multi-Resolution Spectrum Analysis and Sine-on-Random Testing

Application Note 072



Contents

Overview.....	3
Constant Delta F but Logarithmic Frequency Axis.....	3
The traditional approach: using a larger block size.....	3
A new approach: Multi-Resolution.....	4
Application: Sine-on-Random.....	4
Conclusion.....	5

Overview

In this article, we will discuss the benefits of using Multi-Resolution, a feature available in Vibration Control Systems, to offer a better frequency resolution in the lower frequencies of the Sine-on-Random vibration spectrum. The same benefits are also applied to the general Random test, and Random-on-Random mixed mode test.

The Sine-on-Random (SoR) test is a combined form of testing where one or multiple sine tones are excited on top of a random broadband spectrum. The SoR test is a type of Mixed Mode Random test, in addition to the Random-on-Random (RoR) vibration test which excites one or more random narrowbands on top of a broadband profile. (Figure 1.1)

Constant Delta F but Logarithmic Frequency Axis

The Fast Fourier Transform method used to calculate the spectrum returns a spectrum spacing each frequency point evenly apart, where the space between each frequency line is known as the **Frequency Resolution**, or Δf . However, it is conventional to display and analyze the spectrum logarithmically along the frequency x-axis. This results in the relative spacing looking wider in the lower frequencies and finer in the higher frequencies, as shown in the figures below. (Figure 2.1)

The figures above depict the same trapezoidal “navmat” profile being displayed first in log, and then in linear. Indeed, the application of a constant frequency resolution to a logarithmic x-axis results in a perceived deterioration of resolution in the lower left-hand side of the frequency spectrum.

It follows that in a practical vibration test setting, controlling the signal at lower frequencies will become




Figure 1.1 Idealized representation of a Sine-on-Random spectrum




Figure 2.1 Comparison of the same spectrum profile (Amplitude vs. Frequency) in Log and Linear




Figure 2.2 Display of control matching profile with noise in Log and Linear

problematic due to the poorer relative frequency resolution: (Figure 2.2)

The traditional approach: using a larger block size

Usually, an insufficient frequency resolution is addressed by increasing the block size when processing the

data. Mathematically, the block size (number of lines), frequency range, and Δf are related according to the following equation:

$$\text{Frequency Range} = \text{Block Size} \times \Delta f$$

Since the sampling rate, and therefore

range of frequencies, is constant, the density of frequency lines and therefore frequency resolution will be finer.

Thus, increasing the block size is the most direct way to improve the Δf . (Figure 3.1 and Figure 3.2)

The downside to increasing the block size is that the block size will also increase by the same factor, resulting in a slower control loop for processing incoming FFT spectrums. This leaves less time for the controller to react to potential aborts or issues, increasing the security liability.

For instance, a block size of 400 lines and sampling rate of 5120 Hz will result in a Δf of 5.0 Hz and block time of 0.2 seconds. Increasing that block size by 4x to 1600 lines with the same sampling rate will give you a finer Δf of 1.25 Hz, but a correspondingly 4x slower block size of 0.8 seconds.

A new approach: Multi-Resolution

In order to tackle this block size problem from a different angle, a new technique known as Multi-Resolution was developed. Multi-Resolution essentially splits the control spectrum into two parallel control loops: one primary control loop with the original block size, and a secondary control loop with an 8x larger block size dedicated for the lower frequency portion of the spectrum. (Figure 4.1)

In short, the primary control loop responds to alarm / abort scenarios in a timely manner, while the secondary control loop displays and controls the lower frequencies of the spectrum with a finer frequency resolution. Multi-Resolution provides the best of both worlds between control response time and frequency resolution.

Application: Sine-on-Random

Referring to the Sine-on-Random




Figure 3.1 Smaller block size results in poorer frequency resolution




Figure 3.2 Larger block size results in finer frequency resolution

application, one common issue with a poor frequency resolution in the lower frequencies concerns the display of low-frequency sine tones. If a sine tone is located at, say, 5.0 Hz, the peak will be difficult to perceive if the frequency resolution itself is inadequate. Alternatively, it can be difficult to differentiate between two neighboring tones at similar frequencies if the gap between them is on the same order as the frequency resolution itself.

Consider the following MIL-STD-810H Sine-on-Random example, with sine tones at: 5.4, 10.8, 21.6, and 32.4 Hz:

- Block size: 1024 points / 400 lines
- Sampling Rate: 1.24 kHz
- Frequency range: up to 500 Hz
- Block time: 0.8 s
- Frequency resolution Δf :
 - Without MR (top): 1.25 Hz
 - With MR (bottom): $1.25 \text{ Hz} / 8 = 0.156 \text{ Hz}$

(Figure 5.1)

The top figure depicts the control performance without Multi-Resolution. The two Sine tones at 5.4 Hz and 10.8 Hz are difficult to tell apart because the relative frequency resolution of 1.25 Hz is too wide to

differentiate between the energy from each tone. Only when the resolution is increased more, as shown in the Multi-Resolution figure below (MR $\Delta f = 0.156$ Hz) can the two tones be clearly distinguished.

Conclusion

Multi-Resolution is an innovative feature developed to address the tradeoff between finer frequency resolution and faster control loop times. It takes advantage of the insight that good frequency resolution is mostly needed for the lower frequencies and introduces a secondary parallel control loop specifically for handling the lower frequencies with an 8x larger block size and 8x better frequency resolution.

In this article we discuss how it can help with the Random family of tests such as Sine-on-Random, where the sine tones in the lower frequencies are better resolved using Multi-Resolution as an alternative to simply increasing the entire block size. As a result, the vibration test can still preserve a competitive primary alarm / abort reaction time while resolving the lower frequency tones.




Figure 4.1 Simplified diagram of parallel control loops for Multi-Resolution




Figure 5.1 Comparison of Sine-on-Random control with and without Multi-Resolution

Crystal Instruments Corporation
2090 Duane Avenue
Santa Clara, CA 95054

Crystal Instruments Testing Lab
15661 Producer Lane, STE H
Huntington Beach, CA 92649

Crystal Instruments Testing Lab
1548A Roger Dale Carter Boulevard
Kannapolis, NC 28081

Phone: +1 (408) 986-8880
Fax: +1 (408) 834-7818
www.crystalinstruments.com

© 2023 Crystal Instruments Corporation. All Rights Reserved. 07/2023
Notice: This document is for informational purposes only and does not set forth any warranty, expressed or implied, concerning any equipment, equipment feature, or service offered or to be offered by Crystal Instruments. Crystal Instruments reserves the right to make changes to this document at any time, without notice, and assumes no responsibility for its use. This informational document describes features that may not be currently available. Contact a Crystal Instruments sales representative for information on features and product availability.